## **Table of Contents**

General	1
What Does the Plugin Do?	1
Features	1
Supported Database Engines	1
Purpose & Use Cases	2
Installation	2
Requirements	2
Configuration	2
Overview	2
Database-Specific Settings	3
Table-Specific Settings	5
Columns	5
Diagnostics	6
Database	6
Columns	7
Log File	7
Entities	7
Exchange	7
Channel	8
Table	8
Column	8
Folders & Files	8
Folders	8
Files	9
About Versions	9
This Document	9
Plugin	9
Assembly	9

# **SQL Exchange Plugin**

### General

The SQL Exchange Plugin allows you to bidirectionally exchange CoDaBix® datapoint Node values with external databases, such as MySQL, Oracle or Microsoft SQL Server.

## What Does the Plugin Do?

The plugin allows you to:

- define databases (connections)
- browse or define tables
- browse or define table columns
- read and write columns, specifying a Read or Write SQL Expression

### **Features**

- Read columns of a database row (selected by the Read SQL Expression)
- Write columns of a database row by either inserting a new row or updating an existing row (selected by the *Write SQL Expression*)
- Subscribe to columns of a database row when the corresponding CoDaBix® variable Nodes are subscribed to

### **Supported Database Engines**

- MySQL 5.5 or higher
- Microsoft SQL Server 2008 or higher
- Oracle
- SQLite

CoDaBix® - https://www.codabix.com/

### **Purpose & Use Cases**

- Append a table row or update an existing row
- Read data from a table from the latest row or from a specific row
- Create subscriptions to get notified when data in the database is changed
- Call **stored procedures** using method nodes in Codabix (currently only supported for **Oracle** databases)

## Installation

This plugin is part of the CoDaBix® Setup. Please consult CoDaBix® Setup and First Start for more information on how to install and uninstall this plugin.

### Requirements

• The machine which runs CoDaBix® must have access to one of the supported database engines.

## Configuration

#### **Overview**

The entire SQL Exchange Plugin configuration is located under the Node path /System/Exchange/SQL Exchange.

#### 2021/08/02 19:58

3/9

System 5	DE	31					
Devices		Conne	cted.				
Plugins		News	Disalau Masa	Antonia	Malue Trees	Description	Deeb
Interfaces		Name	Display Name	Actual Value	value Type	Description	Path
🔻 📒 Exchange		Settings	Settings			Defines the different settings which	
👻 😯 SQL Exchange		Control	Control			Provides exchange channel control	
Settings		Status	Status			Provides information about the exch	
Control	Ø	Browse	Browse Tables				
Status		Tables	Tables				
👻 🛄 Databases							
👻 👿 DB1							
Settings							
Control							
Status							
👻 🧰 Tables							
🔻 🧮 Table1							
Settings							
Columns							
Nodes							

The Node tree in the image above depicts the SQL Exchange Plugin's default Node tree. To set up one or more SQL Exchange **Databases**, add a Folder Node beneath the Node SQL Exchange / Databases, or right-click on the SQL Exchange / Databases Node and select Add Database.

C 🖬 🖬 🗊	+0 🧪 ವಿಧಿತ	00000	1 15				
System     Devices		Name	Display Name	e Actual Value Va	lue Type	0	)escriptio
<ul> <li>Plugins</li> <li>Interfaces</li> </ul>	Add Database	M. Detabase 4		Developer Norma			×
Exchange     SOL Exchange	Display Name:	My Database 1		Uatabase Name Username	:		
Settings	Server Type:	MySQL	*	Password			
Status     Databases	Port:	3306		Command Timeout	: 50		=
Nodes						~	×

Name	Туре	Description
Server Type	Enum	Defines the server type to which the database connection is established. Valid values: MySQL, Oracle, MSSQL, ODBC, SQLite
Server	String	The hostname or IP address to which the connection shall be established. For <b>SQLite</b> , this is the file path to the database; other connection properties like Port will be ignored.
Port	Integer	The port to which the connection shall be established. When using MSSQL as Server Type, you can specify 0 as port, which means a connection to the default SQL Server instance shall be established.
Database Name	String	The name of the database/scheme. For <b>ODBC</b> , this is the data source name (DSN), and is the only field that needs to be specified. The DSN can be configured on Windows using the <b>ODBC Data Sources</b> app (User DSN or System DSN). Note that for Codabix (x86) you will need to use the 32-bit and for Codabix (x64) the 64-bit ODBC Data Sources app.

### **Database-Specific Settings**

Name	Туре	Description
Username	String	The username for the connection.
Password	Password	The password.
Connect Timeout	Integer	The timeout in seconds after an attempt to connect is canceled.
Command Timeout	Integer	The timeout in seconds after a long-running command is canceled.

After clicking "Save", the database Node will be created. You can start it by selecting the database Node and then clicking the Start button:



To setup one or more **tables** for the database, you can right-click on the database Node and then use the Browse Tables menu entry:



Alternatively, you can right-click on the Tables Node and select Add Table (to edit an existing table, right-click on the Table Node and select Edit Table):

5/9

		👻 🛑 Exchange				
🔻 📒 Databases		👻 😨 SQL Exchange				
👻 🦞 My Datab	ase 1	E Settings	Add Table			×
🕨 🕨 📒 Settings	;	🕨 📒 Control	Name			
🕨 🕨 📒 Control		🕨 📒 Status	Name:			
🕨 📒 Status		💌 📒 Databases	Display Name:			
🧧 Tables		💌 🔽 My Database 1	Table Name:			
Nodes	∓ Add Table	🕨 📒 Settings	Read SQL Expression: 0	RDER BY "ID" DESC		
	+• Access	🕨 📒 Control	Weite COL Evenenciant			
	M& UserGroups	🕨 📒 Status	write SQL Expression:			
	- oser droups	📕 Tables			~	x
		🕨 📒 Nodes				_

### Table-Specific Settings

Name	Туре	Description
Table Name	String	The name of the table in the database.
Read SQL Expression	String	An SQL string (e.g. a WHERE clause or an ORDER BY clause) that is applied when reading the columns. The first row returned by the database is read. You can specify a WHERE clause (e.g. WHERE "ID" = 123) to read only a specific column. The default is ORDER BY "ID" DESC to order the rows by ID descending, so that the row with the highest ID is used.
Write SQL Expression	String	An SQL String (e.g. a WHERE clause) that is applied when writing the columns. You can specify a WHERE clause (e.g. WHERE "ID" = 123) to update an existing row. The default value is an empty string, which means a new row is inserted every time column Nodes are written.

#### Columns

Every Node within the Columns Node of a table Node can be assigned to a column of the table, using the Path property.

C 🕶 🖗 🔟 👘 🖋	0	0 1 1	6					
👻 🧰 System		Name	Display Name	Actual Value	Value Type	Description	Path	Status
Devices		ID	ID	9	Int64		ID	Good
Plugins		SpalteZahl	SpalteZahl	706	Int32		SpalteZahl	Good
Interfaces	D	SpalteText	SpalteText	Neu-für-706	String		SpalteText	Good
👻 📒 Exchange	D	SpalteSyswert	SpalteSyswert		String		SpalteSyswert	Bad: Column is NULL
👻 👽 SQL Exchange	D	SpalteSyswert2	SpalteSyswert2		String		SpalteSyswert2	Bad: Column is NULL
Settings								
Control								
Status								
👻 🛄 Databases								
👻 📝 My Database 1								
Settings								
Control								
Status								
✓ Tables								
* meinetabelle								
Settings								
Columns								
Syntax:								
<columnname></columnname>			Only writin expre	the colu g from / essions a	mn nam to it, th re used	e is spec e table's I	cified. Whe Read SQL	n reading or . or Write SQL

<columnname>; <readwriteexpression></readwriteexpression></columnname>	The column name is specified, along with an expression that is used when reading or writing the column. Example: MyColumn1; WHERE ID = 123
<columnname>; <readexpression>; <writeexpression< td=""><td>The column name is specified, along with an expression that is used when reading from the column, and a separate expression that is used when writing to the column. Example: MyColumn1; WHERE ID = 123; WHERE ID = 456</td></writeexpression<></readexpression></columnname>	The column name is specified, along with an expression that is used when reading from the column, and a separate expression that is used when writing to the column. Example: MyColumn1; WHERE ID = 123; WHERE ID = 456

### **Diagnostics**

The SQL Exchange Plugin provides different status information depending on the layer to inspect. In general the channel-based diagnostic information is produced by the connection status of the channel to the database Server. The variable-based diagnostic information is produced during the read/write access of the different columns. **Database** 

To monitor and diagnose the status of the different databases channels, take a look at the following image:

👻 📃 System	M	My Database 2						
Devices		Access denied for user 'abc'@'localhost' (using password: YES)						
Plugins								
Interfaces		Name	Display Name	Actual Value	Value Type	Description		
🔻 📒 Exchange		Settings	Settings			Defines th		
👻 😨 SQL Exchange		Control	Control			Provides		
Settings		Status	Status			Provides i		
Control	$\Theta$	Browse	Browse Tables					
Status		Tables	Tables					
🔻 📒 Databases					1			
🕨 🙀 My Database 1								
🔻 👿 My Database 2								
Settings								
Control								
Status								
Tables								

The image above depicts the database channel's Control Panel which displays all status relevant information. The control panel will automatically update its status information when a new status is available.

### Status Circle

Color	Meaning
	The database channel is stopped. Click the $\blacktriangleright$ button to start it.
•	The database channel is currently in the progress of starting or stopping or is waiting to establish a connection.

Color	Meaning
•	The database channel is running and a connection has successfully been established. You can stop it by clicking the $\blacksquare$ button.
•	The database channel is running, but the connection is currently in an error state. Please check the status text for more information.
Colum	

#### Columns

To monitor and diagnose the status of the different table columns, take a look at the columns' Status property displayed in CoDaBix. Use the button "Read actual Value" to read the values from the database and store the result into the column nodes.

🖒 🐔 🖏 🏢	#0 <i>(</i>	/ A	2	0 1 1	8					
👻 🧰 Exchange				Name	Display Name	Actual Value	Value Type	Desc	Path	Status
👻 😨 SQL Exchange		^		ID	ID	9	Int64		ID	Good
Settings			D	SpalteZahl	SpalteZahl	706	Int32		SpalteZahl	Good
Control				SpalteText	SpalteText		Int32		SpalteText5	Bad: Unknown column 'SpalteText5' in 'field list
Status										
💌 📃 Databases										
💌 😨 My Database 1										
Settings										
Control										
Status			Π							
🔻 📒 Tables										
🔻 📒 meinetabelle										
Settings										
Columns										
_										

### Log File

All database related status information is also logged into the database-specific log file stored in the [LoggingFolder]. Each log file is named in the naming scheme SQL Exchange.<DatabaseName>.log. The content of such a log file can look as follows:

```
. . .
[14:55:34 25.07.2017] - Error (Severity=High): Code=[-1], Text=[Access
denied for user 'abc'@'localhost' (using password: YES)], Details=[]
. . .
```

### **Entities**

As each exchange plugin the SQL exchange plugin extends the basic CoDaBix Exchange Model.

#### Exchange

The plugin's exchange type SqlExchange also defines the SqlExchangeChannel and therefore extends the basic CodabixExchange and CodabixExchangeChannel entities. While the SqlExchange just represents a concretization of the CodabixExchange, the SqlExchangeChannel extends the CodabixExchangeChannel with the SQL Table entities.

#### Channel

Each channel is handled by a channel worker which establishes a physical connection to the database. For diagnostic purposes, the worker automatically checks the database connection every 10 seconds to update the status code of the Channel and description to detect connection failures.

By default, the worker does not read any values. When a Client or plugin requests a synchronous read of the Channel, the channel worker reads the variables in CoDaBix (e.g. using the CoDaBix Web Configuration's function "Read actual value") from the database and then writes them into the corresponding CoDaBix Nodes.

Similarly, when a Client or plugin writes values into the channel's variables, the channel worker will write those values to the database.

To have an database variable being read steadily, you can edit the Node in the Configuration Web GUI and set "History Options" to Yes (which will create an internal subscription), or you can use e.g. an OPC UA Client connected to the OPC UA Server plugin and create a subscription for the S7 variable Nodes. In these cases, the channel worker reads the variables from the database at a regular interval and, if the value of one of the variables has changed, writes the new value into the corresponding CoDaBix® Node.

#### Table

Each table entity represents the information needed to access a database table. At table level, you can specify how to select the row which the values will be read from or written to.

#### Column

Each column entity represents a single database table column.

### **Folders & Files**

Content	Path	Usage
AssemblyFolder	<codabixinstalldir>/plugins/SqlExchangePlugin/</codabixinstalldir>	Contains the plugin's assembly file.
ConfigFolder	<codabixdatadir>/plugins/SqlExchangePlugin/</codabixdatadir>	Contains the plugin's configuration file.
LoggingFolder	<codabixdatadir>/log/</codabixdatadir>	Contains the plugin's log files.

Files		
Туре	Path	Usage
Assembly	[AssemblyFolder]/CoDaBix.SqlExchangePlugin.dll	The plugin's assembly file.
Logging	<pre>[LoggingFolder]/SQL Exchange.<databasename>.log</databasename></pre>	The log file.

9/9

## **About Versions**

Date	2018-06-15
Version	1.1
Plugin	
Name	SQL Exchange Plugin
Node	/System/Exchange/SQL Exchange
Version	1.0.5
Assembl	у
Name	CoDaBix.SqlExchangePlugin.dll
Date	2019-02-04
Version	1.0.5.0

From: https://www.codabix.com/ - **CoDaBix**®

Permanent link: https://www.codabix.com/en/plugins/exchange/sqlexchangeplugin

Last update: 2021/07/30 13:40