

# Table of Contents

<b>Features</b> .....	1
<b>Purpose &amp; Use Cases</b> .....	1
Purpose .....	1
Use Cases .....	2
<b>Installation</b> .....	2
Requirements .....	2
PLC Settings .....	2
<b>Configuration</b> .....	2
Using CoDaBix .....	2
Channel .....	3
Variables .....	5
Import/Export .....	6
Using the S7 XML Configuration File .....	7
Structure .....	7
Usage .....	12
Synchronization .....	12
Example Configuration File .....	13
Example Configuration Scheme File .....	14
Using the Application (Windows only) .....	16
Overview .....	16
Usage .....	17
<b>Diagnostics</b> .....	18
Channel .....	18
Variables .....	18
Log File .....	19
Status Codes .....	19
<b>Entities</b> .....	20
Device .....	20
Channel .....	20
Variable .....	20
<b>Folders &amp; Files</b> .....	21
Folders .....	21
Files .....	21
<b>About Versions</b> .....	21
This Document .....	21
Plugin .....	21
Assembly .....	21



# S7 Device Plugin

The S7 Device Plugin allows reading and writing values from physical SIMATIC S7 PLC devices via TCP/IP.

The following device types are supported:

- S7-1500 (see [PLC Settings](#))
- S7-1200 (see [PLC Settings](#))
- S7-300
- S7-400
- WinAC
- S7-SoftPLC
- LOGO! (see [PLC Settings](#))
- S7-200
- SIMATIC S5 over S5-LAN
- S7-LAN
- VIPA-S7 and any other S7-TCP/IP compatible PLC

## Features

- Optimized read and write requests by using the best utilization regarding the package size.
- Automated connection handling including auto-reconnect.
- Accessing PLC memory using user defined types.
- Use of existing PLC projects to set up channels and variables. The following project formats are supported:
  - STEP7 Project Files (\*.s7p)
  - IP-S7 Project Files (\*.ips7)
  - S7 Watch Project Files (\*.wproj)
  - CSV-to-S7 Project Files (\*.ini)

## Purpose & Use Cases

### Purpose

The linked devices can simply be controlled using CoDaBix®. By linking the PLC memory to the Nodes defined in CoDaBix® the PLC can directly interact with many other Nodes, devices, services, etc. maintained in CoDaBix®. Also other CoDaBix® participants can interact with the PLC devices linked through the S7 Device Plugin.

## Use Cases

- Dynamic generation of manufacturing jobs based on different conditions and data produced by machines, users, orders, condition, services, etc.
- Additional reliability by monitoring the whole plant including inter-plant interaction
- Centralized controller and flow surveillance for early diagnosis of possible failures
- Possibilities to improve the Shop Floor Management by monitoring and recording production data produced by the devices

## Installation

This plugin is part of the CoDaBix® Setup. Please consult [CoDaBix® Setup and First Start](#) for more information on how to install and uninstall this plugin.

### Requirements

- Basic requirements of CoDaBix
- Enabled outgoing TCP/IP connection via port 102

### PLC Settings


Please note that in order to access the S7-1200, S7-1500 and the LOGO!, the **optimized data block access** has to be **deactivated** at the data block attributes.

To do that, you can find instructions at: [Deactivate optimized data block access](#).

## Configuration

### Using CoDaBix

The whole S7 Device Plugin configuration is located in the node path /System/Devices/S7 Device.



## Channel

An S7 Device Channel represents the connection to a S7 PLC.

### Settings

#### Address

IP address or hostname of the S7 PLC.

#### Rack

The rack number of the PLC device.

#### Slot

The slot number of the PLC device.

#### Device Type

The device type of the SIMATIC S7 PLC. The following device types are supported:

- LOGO!
- S7-200
- S7-300
- S7-400
- S7-1200
- S7-1500

## Channel Type

The type of device channel to use to communicate with the PLC.

## DateTime Interpretation

Specifies how the timezone of read and written DateTime values should be interpreted (are the date/time values in the PLC stored as UTC time or as local time).


## Solve Siemens PDU Bug

Specifies if a reduced PDU size should be used to work-around an issue in some S7-400 devices which would otherwise randomly truncate a large data packet, resulting in an error like “specified data area doesn't exist”.

## Is Simulation

Specifies whether this device runs in simulation mode, which means no connection to a physical device is established.

## Adding a Channel



To add a new S7 Channel, please follow these steps:

1. Add a Folder Node within the node S7 Device/Channels, or right-click on the S7 Device/Channels node and select Add Channel.
2. In the Add Channel dialog, specify the settings for the S7 connection.
3. After clicking on “Save”, the channel node is created.

4. You can start the channel by selecting the channel node and clicking the start button.

## Variables

Within the node **Variables** you can create datapoint nodes which can be read and written from/to the S7. Additionally, you can import variables e.g. from a **STEP7** project.

The **Value Type** property must be set to the corresponding S7 Device type. Currently the following types are supported in the S7 Device Plugin:

<b>S7 Device Type</b>	<b>PLC Type</b>	<b>Preferred CoDaBix Value Type</b>	<b>Description</b>
Bool	BOOL	Boolean or Boolean-Array	A variable of the PLC type BOOL.
Byte	BYTE	Byte or Byte-Array	A variable of the PLC type BYTE.
Char	CHAR	String or String-Array	A variable of the PLC type CHAR.
Int	INT	Int16 or Int16-Array	A variable of the PLC type INT. Representing a signed 16 bit integer.
Word	WORD	UInt16 or UInt16-Array	A variable of the PLC type WORD. Representing an unsigned 16 bit integer.
DInt	DINT	Int32 or Int32-Array	A variable of the PLC type DINT. Representing a signed 32 bit integer.
DWord	DWORD	UInt32 or UInt32-Array	A variable of the PLC type DWORD. Representing an unsigned 32 bit integer.
LInt	LINT	Int64 or Int64-Array	A variable of the PLC type LINT. Representing a signed 64 bit integer.
LWord	LWORD	UInt64 or UInt64-Array	A variable of the PLC type LWORD. Representing an unsigned 64 bit integer.
Real	REAL	Single or Single-Array	A variable of the PLC type REAL. Representing a single precision floating point number.
Double	REAL	Double or Double-Array	A variable of the PLC type REAL. Representing a double precision floating point number.
LReal	LREAL	Double or Double-Array	A variable of the PLC type LREAL. Representing a double precision floating point number.
Date	DATE	DateTime or DateTime-Array	A variable of the PLC type DATE.
Time	TIME	TimeSpan or TimeSpan-Array	A variable of the PLC type TIME.
TimeOfDay	TOD/TIME_OF_DAY	TimeSpan or TimeSpan-Array	A variable of the PLC type TOD/TIME_OF_DAY.

S7 Device Type	PLC Type	Preferred CoDaBix Value Type	Description
S5Time	S5TIME	TimeSpan or TimeSpan-Array	A variable of the PLC type S5TIME.
DateTime	DT/DATE_AND_TIME	DateTime or DateTime-Array	A variable of the PLC type DT/DATE_AND_TIME.
DateTimeLong	DTL	DateTime or DateTime-Array	A variable of the PLC type DTL.
String	STRING	String	A variable of the PLC type STRING.
S5String	BYTE	String	A variable of the PLC type BYTE. A fixed number of bytes is interpreted as string.

## Path

The Path property of the node is used to specify the address, optionally a type, and (for arrays or strings) the length:

```
<Address>
<Address>, <Length>
<Address>, <Type>
<Address>, <Type>[<Length>]
```

Placeholder	Description
<Address>	The address of the data. Example: DB10.DBW 16
<Length>	If the variable is an array or a string, specify the array/string length here. It will only be used for reading, because when writing an array/string, its length will be determined from the value that is written.
<Type>	If present, contains the S7 Device Type (see table above) which will override the default type inferred from the CoDaBix Value Type. Note: When using CoDaBix Value Type Double, The S7 Device Type is not automatically inferred; you will need to specify Double explicitly.


## Examples

CoDaBix Value Type	Path	Meaning
Boolean	DB10.DBX 3.2	Single bit (BOOL) at address DB10.DBX 3.2
Boolean-Array	DB10.DBX 3.4, 18	Bit (BOOL) array from address DB10.DBX 3.4 to DB10.DBX 5.6 (exclusive)
Int32	DB10.DBD 12, DInt	Single DInt (DINT) at address DB10.DBW 12
Double-Array	DB10.DBD 20, Double[5]	Double-Array (REAL) from address DB10.DBD 20 to DB10.DBD 40 (exclusive)
String	DB10.DBB 40, 100	String (STRING) from address DB10.DBB 40 to DB10.DBB 142 (exclusive)
String	DB10.DBB 40, S5String[100]	S5String (BYTE) from address DB10.DBB 40 to DB10.DBB 140 (exclusive)

## Import/Export

The S7 Device Plugins supports importing and exporting individual channels as S7 XML Configuration

file (see next section). Additionally, you can import a **STEP7** project (.s7p) that has been packed into a ZIP file into a channel. The import and export options are shown when right-clicking on a specific channel:



To import a configuration file or STEP7 project as a new channel, create a new channel first (with default settings), then right-click on the channel to open the import dialog.

## Using the S7 XML Configuration File

### Structure

The S7 Device Plugin defines the root of its element tree by the `PluginSettings` element as described in [Plugin Configuration - Using a Configuration File](#) and continues its XML tree using the `Channel` element.

### Channel Element

The `Channel` element serves as the container for the elements `Settings` and `Variables`. One channel identifies one PLC connection to which the channel configuration belongs. This information is therefore used by the S7 Device Plugin to link the PLC to CoDaBix®.

The `Channel` element can look as follows:

```
<Channel>
  <Settings />
  <Variables />
</Channel>
```

### Settings Element

The **Settings** element defines the attributes to setup the channel. These attributes configure the channels connection parameters.

The **Settings** element can look as follows:

```
<Settings Address="192.168.0.80"
          Rack="0"
          Slot="2"
          ChannelType="OperationPanel"
          DeviceType="S7400" />
```

The **Settings** element provides the following list of attributes:

	<b>Mandatory</b>	<b>Type</b>	<b>Purpose</b>
<b>Address</b>	<b>yes</b>	String	The IP Address of the PLC device to link.
<b>Rack</b>	no	Int32	The rack number of the PLC device.
<b>Slot</b>	no	Int32	The slot number of the PLC device.
<b>ChannelType</b>	no	S7 Device Channel Type	The type of device channel to use to communicate with the PLC.
<b>DeviceType</b>	no	S7 Device Type	The type of PLC device.

### S7 Device Channel Type

The following values are valid for attributes of that type:

<b>Value</b>	<b>Description</b>
“OperationPanel”	To connect via OP channel to the device.
“ProgrammerDevice”	To connect via PG channel to the device.
“Other”	To connect to the device using alternative channels.

### S7 Device Type

The following values are valid for attributes of that type:

<b>Value</b>	<b>Description</b>
“Logo”	SIEMENS LOGO!
“S7200”	SIMATIC S7-200
“S7300”	SIMATIC S7-300
“S7400”	SIMATIC S7-400
“S71200”	SIMATIC S7-1200
“S71500”	SIMATIC S7-1500

## **Variables Element**

The **Variables** element serves as the container for one or more **Variable** elements. This element maintains all variables associated with the channel.

The **Variables** element can look as follows:

```
<Variables>
  <!-- 0-n Variable elements -->
```

`</Variables>`

## Variable Element

The Variable element serves as the container for the element Variables. One variable identifies one addressable area in the memory of the PLC or a set of subsequent variables identify multiple addressable areas in the memory of the PLC. This information is therefore used by the S7 Device Plugin to link the PLC memory to CoDaBix® Nodes.

Each Variable element provides the following list of attributes:

	<b>Mandatory</b>	<b>Type</b>	<b>Purpose</b>
<b>Identifier</b>	no	GUID	The generic unique identifier of the entity associated with the variable. <i>This is a generic entity attribute, for more information about its usage see <a href="#">Plugin Configuration - Using a Configuration File</a>: The Entities Identifier Attribute.</i>
<b>ChangeType</b>	no	ChangeType	The state of the entity configuration used to represent the variable. <i>This is a generic entity attribute, for more information about its usage see <a href="#">Plugin Configuration - Using a Configuration File</a>: The Entities ChangeType Attribute.</i>
<b>Name</b>	<b>yes</b>	String	The unique name (within the Variables element) of the variable.
<b>Description</b>	no	String	The description of the usage and purpose of the addressed memory area.
<b>Address</b>	<b>yes</b>	PLC Address	The operand to use to address the memory of the PLC (not supported in this case: Type=“Object”).
<b>Type</b>	<b>yes</b>	PLC Variable Type	The type of data stored at the addressed memory and how it is to be interpreted.
<b>Length</b>	no	Int32	The length of an array or string variable (only supported on Type=“String” and numerical Types). If this attribute is defined the variable defines an array value (if supported), otherwise a scalar value.

### PLC Variable Type

The following values are valid for attributes of that type:

<b>Value</b>	<b>Description</b>
“Bool”	A variable of the PLC type BOOL.
“Byte”	A variable of the PLC type BYTE.
“Char”	A variable of the PLC type CHAR.
“Int”	A variable of the PLC type INT. Representing a signed 16 bit integer.
“Word”	A variable of the PLC type WORD. Representing an unsigned 16 bit integer.
“DInt”	A variable of the PLC type DINT. Representing a signed 32 bit integer.
“DWord”	A variable of the PLC type DWORD. Representing an unsigned 32 bit integer.
“Real”	A variable of the PLC type REAL. Representing a single precision floating point number.

<b>Value</b>	<b>Description</b>
"Double"	A variable of the PLC type REAL. Representing a double precision floating point number.
"Date"	A variable of the PLC type DATE.
"Time"	A variable of the PLC type TIME.
"TimeOfDay"	A variable of the PLC type TOD/TIME_OF_DAY.
"S5Time"	A variable of the PLC type S5TIME.
"DateTime"	A variable of the PLC type DT/DATE_AND_TIME.
"DateTimeLong"	A variable of the PLC type DTL.
"String"	A variable of the PLC type STRING.
"S5String"	A variable of the PLC type BYTE. A fixed number of bytes is interpreted as string.

### PLC Variable Address

The following Operand and Data Type combinations are valid to construct a valid PLC variable address:

#### Operands

<b>Operand</b>	<b>Siemens, DE</b>	<b>IEC</b>
Input	E	I
Output	A	Q
Flag	M	M
Peripherals	P	P
Counter	Z	C
Data Block	DB	DB
Timer	T	T

#### Data Types

<b>Data Type</b>	<b>Operand</b>	<b>Bits</b>	<b>Range</b>	<b>Description</b>
BOOL	X	1	0 to 1	A single bit representing true (1) or false (0).
BYTE	B	8	0 to 255	An unsigned 8-bit integer.
WORD	W	16	0 to 65.535	An unsigned 16-bit integer (Word).
DWORD	D	32	0 to $2^{32}-1$	An unsigned 32-bit integer (Double Word).
CHAR	B	8	A+00 to A+ff	An ASCII-Code as an unsigned 8-bit character.
INT	W	16	-32.768 to 32.767	A signed 16-bit integer.
DINT	D	32	$-2^{31}$ to $2^{31}-1$	A signed 32-bit integer (Double Word).
REAL	D	32	+1.5e-45 to +3.4e38	An IEEE754 32-bit single precision floating point number.
S5TIME	W	16	00.00:00:00.100 to 00.02:46:30.000	A binary coded decimal (BCD) number representing a time span.
TIME	D	32	00.00:00:00.000 to 24.20:31:23.647	A signed 16-bit integer representing a time span in milliseconds.

Data Type	Operand	Bits	Range	Description
TIME_OF_DAY	D	32	00.00:00:00.000 to 00.23:59:59.999	An unsigned 16-bit integer representing a time span in milliseconds.
DATE	W	16	01.01.1990 to 31.12.2168	An unsigned 16-bit integer representing a date in days.
DATE_AND_TIME	D	64	00:00:00.000 01.01.1990 to 23:59:59.999 31.12.2089	A binary coded decimal (BCD) number representing a date and time.

### Examples

Example	Data type	Siemens	IEC
Input Byte 1, Bit 0	BOOL	E 1.0	I 1.0
Output Byte 1, Bit 7	BOOL	A 1.7	Q 1.7
Flag Byte 10, Bit 1	BOOL	M 10.1	M 10.1
Data Block 1, Byte 1, Bit 0	BOOL	DB1.DBX 1.0	DB1.DBX 1.0
Input Byte 1	BYTE	EB 1	IB 1
Output Byte 10	BYTE	AB 10	QB 10
Flag Byte 100	BYTE	MB 100	MB 100
Peripherals Input Byte 0	BYTE	PEB 0	PIB 0
Peripherals Output Byte 1	BYTE	PAB 1	PQB 1
Data Block 1, Byte 1	BYTE	DB1.DBB 1	DB1.DBB 1

The Variable element can look as follows:

```
<Variable Name="Active Rotations"
  Type="DInt"
  Address="DB101.DB0 0" />
```

The Variable element with the Type attribute and the attribute value "Object" can look as follows:

```
<Variable Name="Mill Job No. 1" Description="Identifies the mill job
no. 1" Type="Object">
  <Variables>
    <Variable Name="Rotations" Type="DInt" Address="DB200.DB0 0" />
    <Variable Name="Use Colling" Type="Bool" Address="DB200.DBX 4.0" />
    <Variable Name="Use Fan" Type="Bool" Address="DB200.DBX 4.1" />
    <Variable Name="Point 1" Type="Object">
      <Variables>
        <Variable Name="X" Description="The x portion of the drill." />
        <Variable Name="Y" Description="The y portion of the drill." />
      </Variables>
    </Variable>
    <Variable Name="Point 2" Type="Object">
      <Variables>
```

```

<Variable Name="X" Description="The x portion of the drill."
Type="Int" Address="DB200.DBW 9" />
    <Variable Name="Y" Description="The y portion of the drill."
Type="Int" Address="DB200.DBW 11" />
        </Variables>
    </Variable>
<Variable Name="Point 3" Type="Object">
    <Variables>
        <Variable Name="X" Description="The x portion of the drill."
Type="Int" Address="DB200.DBW 13" />
            <Variable Name="Y" Description="The y portion of the drill."
Type="Int" Address="DB200.DBW 15" />
                </Variables>
            </Variable>
        </Variables>
    </Variable>
</Variables>
</Variable>

```

## Usage

It is recommended to use a professional XML editor when editing the configuration file manually. To also benefit from the XML schema definition mentioned at the end of this article you have to refer to the schema definition by using the `xsi:noNamespaceSchemaLocation` attribute in the document root element `PluginSettings` as follows (the XSD file needs to be placed next to the XML file):

```

<?xml version="1.0" encoding="utf-8" ?>
<PluginSettings xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
xsi:noNamespaceSchemaLocation="CoDaBix.S7DevicePlugin.Settings.xsd">
    <!-- child elements -->
</PluginSettings>

```

Independent from editing / creating the configuration file manually or automated, the element tree above documented must be fulfilled to produce a valid, well-formed and usable configuration file.

## Synchronization

An S7 XML Configuration file is assigned to a S7 Device Channel in CoDaBix for **automatic synchronization**, if the following condition is true:

- A file with the name `CoDaBix.S7DevicePlugin.<ChannelName>.Settings.xml` exists in the `ConfigFolder (<CodabixProjectDir>/plugins/S7DevicePlugin)` when starting the S7 Plugin (i.e. when starting CoDaBix) or when creating a new channel in CoDaBix.

In that case, once the configuration file changes, it is automatically synchronized into CoDaBix. Also, when the variables in CoDaBix (or the channel settings) are changed, the changes are synchronized into the configuration file.

Regardless of the automatic synchronization, you can also use manual synchronization by right-clicking on a S7 Device Channel in CoDaBix and selecting the corresponding

Import/Export menu item.

## Example Configuration File

CoDaBix.S7DevicePlugin.Settings.xml

```
<?xml version="1.0" encoding="utf-8"?>
<PluginSettings>
    <Channel>
        <Settings Address="192.168.0.80" ChannelType="OperationPanel"
DeviceType="S7400" />
        <Variables>
            <Variable Name="Active Job Name" Type="String"
Address="DB100.DBB 0" Length="64" />
            <Variable Name="Active Job Number" Type="String"
Address="DB100.DBB 80" Length="8" />
            <Variable Name="Active Rotations" Type="DInt"
Address="DB101.DB0 0" />
            <Variable Name="Mill Job No. 1" Description="Identifies the
mill job no. 1" Type="Object">
                <Variables>
                    <Variable Name="Rotations" Type="DInt"
Address="DB200.DB0 0" />
                    <Variable Name="Use Colling" Type="Bool"
Address="DB200.DBX 4.0" />
                    <Variable Name="Use Fan" Type="Bool" Address="DB200.DBX
4.1" />
                    <Variable Name="Point 1" Type="Object">
                        <Variables>
                            <Variable Name="X" Description="The x portion of the
drill." Type="Int" Address="DB200.DBW 5" />
                            <Variable Name="Y" Description="The y portion of the
drill." Type="Int" Address="DB200.DBW 7" />
                        </Variables>
                    </Variable>
                    <Variable Name="Point 2" Type="Object">
                        <Variables>
                            <Variable Name="X" Description="The x portion of the
drill." Type="Int" Address="DB200.DBW 9" />
                            <Variable Name="Y" Description="The y portion of the
drill." Type="Int" Address="DB200.DBW 11" />
                        </Variables>
                    </Variable>
                    <Variable Name="Point 3" Type="Object">
                        <Variables>
                            <Variable Name="X" Description="The x portion of the
drill." Type="Int" Address="DB200.DBW 13" />
                            <Variable Name="Y" Description="The y portion of the
drill." Type="Int" Address="DB200.DBW 15" />
                        </Variables>
                    </Variable>
                </Variables>
            </Variable>
        </Variables>
    </Channel>
</PluginSettings>
```

```
        </Variables>
    </Variable>
</Variables>
</Channel>
</PluginSettings>
```

## Example Configuration Scheme File

### CoDaBix.S7DevicePlugin.Settings.xsd

```
<?xml version="1.0" encoding="utf-8"?>
<xss: schema id="CoDaBix.S7DevicePlugin.Settings"
    elementFormDefault="qualified"
    xmlns:xss="http://www.w3.org/2001/XMLSchema">
<xss:simpleType name="Guid">
    <xss:restriction base="xs:string">
        <xss:pattern value="([0-9a-fA-F]{8}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-[0-9a-fA-F]{12})|(\{[0-9a-fA-F]{8}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-[0-9a-fA-F]{12}\})"/>
    </xss:restriction>
</xss:simpleType>

<xss:simpleType name="PlcAddress">
    <xss:restriction base="xs:string">
        <xss:pattern value="^[\t]*(DB[\t]*([\d+][\t]*.\.[\t]*(DB))|(((Z|C)|DB|M|(E|I)|L|(A|Q)|(PE|PI)|(PA|PQ)|T)))[\t]*((X|B|W|D))?[ \t]*([\d+](\.( [\d+]))?\b" />
    </xss:restriction>
</xss:simpleType>

<xss:simpleType name="VariableEnumType">
    <xss:restriction base="xs:string">
        <xss:enumeration value="Bool" />
        <xss:enumeration value="Byte" />
        <xss:enumeration value="Char" />
        <xss:enumeration value="Int" />
        <xss:enumeration value="Word" />
        <xss:enumeration value="DInt" />
        <xss:enumeration value="DWord" />
        <xss:enumeration value="Real" />
        <xss:enumeration value="Double" />
        <xss:enumeration value="Date" />
        <xss:enumeration value="Time" />
        <xss:enumeration value="TimeOfDay" />
        <xss:enumeration value="S5Time" />
        <xss:enumeration value="DateTime" />
        <xss:enumeration value="String" />
        <xss:enumeration value="S5String" />
    </xss:restriction>
```

```
</xs:simpleType>

<xs:complexType name="VariableType">
  <xs:sequence>
    <xs:element name="Variables" type="VariablesType"
minOccurs="0" maxOccurs="1" />
  </xs:sequence>

    <xs:attribute name="Identifier" type="Guid" use="required" />
    <xs:attribute name="Name" type="xs:string" use="required" />
    <xs:attribute name="Description" type="xs:string"
use="optional" />
    <xs:attribute name="Address" type="PlcAddress" use="optional"
/>
    <xs:attribute name="Type" type="VariableEnumType"
use="required" />
    <xs:attribute name="Length" type="xs:integer" use="optional"
default="-1" />
  </xs:complexType>

  <xs:complexType name="VariablesType">
    <xs:sequence>
      <xs:element name="Variable" type="VariableType"
minOccurs="0" maxOccurs="unbounded" />
    </xs:sequence>
  </xs:complexType>

<xs:simpleType name="ChannelDeviceEnumType">
  <xs:restriction base="xs:string">
    <xs:enumeration value="Logo" />
    <xs:enumeration value="S7200" />
    <xs:enumeration value="S7300" />
    <xs:enumeration value="S7400" />
    <xs:enumeration value="S71200" />
    <xs:enumeration value="S71500" />
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name="ChannelEnumType">
  <xs:restriction base="xs:string">
    <xs:enumeration value="OperationPanel" />
    <xs:enumeration value="ProgrammerDevice" />
    <xs:enumeration value="Other" />
  </xs:restriction>
</xs:simpleType>

  <xs:complexType name="ChannelSettingsType">
    <xs:attribute name="Address" type="xs:string" use="required"
/>
    <xs:attribute name="Rack" type="xs:integer" use="optional"
default="0" />
```

```
<xs:attribute name="Slot" type="xs:integer" use="optional"
default="2" />
<xs:attribute name="ChannelType" type="ChannelEnumType"
use="optional" default="OperationPanel" />
<xs:attribute name="DeviceType" type="ChannelDeviceEnumType"
use="optional" default="S7300" />
</xs:complexType>

<xs:complexType name="ChannelType">
<xs:sequence>
<xs:element name="Settings" type="ChannelSettingsType"
minOccurs="0" maxOccurs="1" />
<xs:element name="Variables" type="VariablesType"
minOccurs="0" maxOccurs="1" />
</xs:sequence>
</xs:complexType>

<xs:complexType name="PluginSettingsType">
<xs:sequence>
<xs:element name="Channel" type="ChannelType" minOccurs="0"
maxOccurs="1" />
</xs:sequence>
</xs:complexType>


<xs:element name="PluginSettings" type="PluginSettingsType" />
</xs:schema>
```

## Using the Application (Windows only)

**Note:** The configuration application allows you to load and save S7 XML Configuration Files (.xml) that can be imported and exported on a S7 Device Channel in CoDaBix (using the context menu), or that are assigned to an CoDaBix S7 Device Channel for automatic synchronization (see section [Using the S7 XML Configuration File](#)).

The configuration application resides in the folder <CodabixInstallDir> and is started by double-clicking the file with the name CoDaBix.S7DevicePlugin.Configurator.exe.

### Overview



## Usage

- Add a new Channel in the left list by clicking the upper plus button.
  - Set the name of the channel by clicking its name in the right pane.
  - Set up the Channel Settings like the IP Address (at least required).
  - Optionally set the appropriate Device Type and select the Channel Type to be used.
  - Optionally set the Rack and Slot (in case it differs from the defaults).
- Add a new Variable to the Channel in the second from the left list by clicking the upper first button with the plus sign.
  - Set up the name of the variable by clicking its name in the right pane.
  - Optionally set the description of the variable by clicking in the free area beneath the variable name.
  - Set up the PLC address operand to be used to access the PLC memory for that variable.
  - Set up the PLC variable type in the combo and enter, in case of a string or an array (check the option Is Array) variable, the appropriate length of the variable.
  - Optionally add additional variables in case the previously added variable is of the type "Object". Do that by selecting the object variable in the left tree and then click the second add button with the plus sign above.
- To remove a variable, select it in the tree and click on the button with the minus sign above.
- To remove a channel, select it in the left list and click on the button with the minus sign above.
- Using the Import Project button it is possible to import the following project formats:
  - STEP7 Project Files (\*.s7p)
  - IP-S7 Project Files (\*.ips7)


- S7 Watch Project Files (\*.wproj)
- CSV-to-S7 Project Files (\*.ini)

## Diagnostics

The S7 Device Plugin provides different status information depending on the layer to inspect. In general the channel based diagnostic information is produced by the connection status of the channel to the S7 PLC. The variable based diagnostic information is produced during the read/write access of the different variables.

### Channel

To monitor and diagnose the status of a S7 Channel, take a look at the following image:



The image above depicts the S Channel's Control Panel which displays all status relevant information. The control panel will automatically update its status information when a new status is available.

### Status Circle

Color	Meaning
Grey	The channel is stopped. Click the ► button to start it.
Yellow	The channel is currently in the progress of starting or stopping or is waiting to establish a connection.
Green	The channel is running and a connection has successfully been established. You can stop it by clicking the ■ button.
Red	The channel is running, but the connection is currently in an error state. Please check the status text for more information.

### Variables

To monitor and diagnose the status of the different S7 variables take a look at the variable's Status Code property displayed in CoDaBix®.

In case the Status Code column displays the value Bad in most cases the addressed data

area is not accessible.

The screenshot shows the S7 Device Plugin interface. On the left, there is a tree view of device nodes under 'System > Devices > S7 TCP-IP Device'. Nodes include 'Mill Job No. 1', 'Active Job Name', 'Active Job Number', and 'Active Rotations'. On the right, a table lists these parameters with their values and status codes:

Name	Display Name	Description	Value Type	Path	Actual Value	Status code
Mill Job No. 1	Mill Job No. 1			Object	---	
Active Job Name	Active Job Name		String	DB10000.DBB 0, String[64]		Bad
Active Job Number	Active Job Number		String	DB100.DBB 80, String[8]	1549231	Good
Active Rotations	Active Rotations		Int32	DB101.DBD 0, DInt		Bad

## Log File

All device channel related status information is also logged into the channel-specific log file stored in the [LoggingFolder]. Each log file is named in the naming scheme S7 Device.<ChannelName>.log. The content of such a log file can look as follows:

```
...
[15:31:46 05.09.2016] - Error (Severity=High): Code=[ -6 ], Text=[The specified CPU could not be found.]
```

Using the sample channel the name of the log file would be: S7\_Device.Line\_Controller.log

## Status Codes

The following table displays the different status information possible:

Code	Category	Severity	Text
-88	Error	High	The operation has been canceled.
-34	Error	High	The requested PLC block could not be found.
-33	Error	High	The PLC does not support bit based operations.
-32	Error	High	The PLC supplied truncated data.
-31	Error	High	The requested PLC or PC type of data can not be transformed from one to the other.
-30	Error	High	The requested PLC or PC type of data is not available.
-21	Error	High	A connection to the device has already been established.
-20	Error	High	The size of the supplied buffer is lower than the amount of data available.
-11	Error	High	The type or format of data supplied is not supported.
-10	Error	High	The supplied access mode is not supported or unknown.
-9	Error	High	The operation failed upon a value range error.
-8	Error	High	Failed to allocate required memory.
-7	Error	High	The operation failed upon a socket error.
-6	Error	High	The specified CPU could not be found.
-5	Error	High	A general error occurred.
-2	Error	High	The necessary memory could not be allocated (out of memory).
-1	Error	High	The operation has timed out.
0	Information	Moderate	The operation completed without any kind of error.

<b>Code</b>	<b>Category</b>	<b>Severity</b>	<b>Text</b>
1	Information	Moderate	The operation completed successfully.
2	Information	Moderate	The addressed data area does not exist.

## Entities

As each device plugin the S7 device plugin extends the basic CoDaBix [Device Model](#).

### Device

The plugin's device type `S7Device` also defines the `S7DeviceChannel` and therefore extends the basic `CodabixDevice` and `CodabixDeviceChannel` entities. While the `S7Device` just represents a concretization of the `CodabixDevice`, the `S7DeviceChannel` extends the `CodabixDeviceChannel` with the S7 Variable Entities.

### Channel

Each channel is handled by a Channel Worker which establishes a physical connection to the S7 device. For diagnostic purposes, the worker automatically reads the PLC address "MB 0" every 10 seconds to update the status code of the Channel and description to detect connection failures.

By default, the worker does not read any values. When a client or plugin requests a synchronous read of the Channel variables in CoDaBix (e.g. using the CoDaBix Web Configuration's function "Read actual value"), the channel worker reads them from the underlying S7 device and then writes them into the corresponding CoDaBix Nodes.

Similarly, when a Client or plugin writes values into the channel's variables, the channel worker will write those values to the underlying S7 device.

To have an S7 variable being read steadily, you can edit the Node in the CoDaBix Web Configuration and set "History Options" to Yes (which will create an internal subscription), or you can use e.g. a OPC UA Client connected to the OPC UA Server plugin and create a subscription for the S7 variable Nodes. In these cases, the channel worker reads the variables from the S7 at a regular interval and, if the value of one of the variables has changed, writes the new value into the corresponding CoDaBix Node.

### Variable

Each S7 variable can access the same PLC memory using the same PLC address operand. However, its interpretation depends on the PLC Data Type selection. Supported variable formats are scalar, array and object variables. Variables of the type `Object` can own further variables and are defined as `UserDefinedTypes` (UDT in STEP7).

# Folders & Files

## Folders

Content	Path	Usage
AssemblyFolder	<CodabixInstallDir>/plugins/S7DevicePlugin/	Contains the plugin's assembly file.
ConfigFolder	<CodabixDataDir>/plugins/S7DevicePlugin/	Contains the plugin's configuration file.
LoggingFolder	<CodabixDataDir>/log/	Contains the plugin's log files.

## Files

Type	Path	Usage
Assembly	[AssemblyFolder]/CoDaBix.S7DevicePlugin.dll	The plugin's assembly file.
Config App	<CodabixInstallDir>/CoDaBix.S7DevicePlugin.Configurator.exe	The config application file.
Config File	[ConfigFolder]/CoDaBix.S7DevicePlugin.<ChannelName>.Settings.xml	The optional channel config file.
Logging	[LoggingFolder]/S7 Device.<ChannelName>.log	The log file.

# About Versions

## This Document

Date	2020-12-01
Version	1.3

## Plugin

Name	S7 Device Plugin
Node	/System/Devices/S7 Device
Version	1.2.0

## Assembly

Name	CoDaBix.S7DevicePlugin.dll
Date	2020-12-01
Version	1.2.0.0

From:  
<https://codabix.de/> - CoDaBix®

Permanent link:  
<https://codabix.de/en/plugins/device/s7deviceplugin>

Last update: **2022/07/28 17:09**